


# ANTENNA CUTTING CHART

V/01

MODEL **CAT480**



**Entel**

IMPORTANT: antenna must be cut to centre transmit frequency & cap glued before use

5